

Maintenance Bulletin Tri-Max 3 Mini CAF

- **Hydrostatically Test Canister Every 5 Years @ 200psi**
- **Hydrostatically Test Air Bottle Every 5 Years @5000psi**
- **Replace Check Valve if needed**
- **Remove air line from regulator. If airline is corroded, replace check valve**
- **Replace check valve if there are signs of corrosion**
- **If check valve has had a failure, the regulator will need to be replaced**

**If you need assistance with spare parts,
please contact the parts department @ (530) 722-0272 ext. 708**

August 30, 2018