

## Maintenance Bulletin Tri-Max 30

- **Hydrostatically Test Solution Tank Every 5 Years @ 300psi**
- **Hydrostatically Test Air Bottles Every 5 Years @5000psi**
- **Hydrostatically Test Booster Hose Every 5 Years @ 300psi**
- **Remove Airline from manifold and make sure airline is not clogged**
- **Remove airline from low pressure check valve to regulator. If airline is showing signs of corrosion, check valve has failed. The regulator and check valve will need to be replaced.**
- **Cycle relief valve and spray down with WD40 or equivalent. If relief valve is corroded it will need to be replaced.**
- **Remove 1 ½” plug at the rear of the tank and inspect tank liner. If liner is coming off, there is a possibility the liner could clog up the pick-up tube. If this is visible, the tank will need to be replaced.**

**If you need assistance with spare parts,  
please contact the parts department @ (530) 722-0272 ext. 708**

**August 30, 2018**